

# COTTON CANDY INSTRUCTIONS

Loosen silver stabilizer screws to release floss head.

Set floss pan on machine and assemble bubble.

Fill floss head to 90% full.

Turn on main switch and heat switch.

When stopping operation for the day, run all the sugar out of the floss head.

When empty, turn the heat to the highest position for approximately one minute to remove carbonization from the ribbons.

**NEVER ALLOW WATER TO ENTER THE FLOSS HEAD.**

Tighten silver stabilizer screws for transport.

Clean floss pan, plastic whirl grip, plastic bubble and cone holder with mild soapy water before returning.

Return equipment clean to avoid a cleaning fee.

Thank you.

